

■ การเลือกรุ่น

VR06- - -
1 2 3 4 5 6 7 8 9 10

1 Power

- 4 : 90 - 264 VAC, 47 - 63 Hz
- 5 : 20 - 28 VAC, 47 - 63 Hz
- 6 : 11-18 VDC
- 7 : 18 - 36 VDC

2 Analog Input Card

- 0 : None
- 1 : 1 Channels
- 2 : 2 Channels
- 3 : 3 Channels
- 4 : 4 Channels
- 5 : 5 Channels
- 6 : 6 Channels

3 Digital Input Card

- 0 : None
- 1 : 6 Channels
- 2 : 12 Channels

4 Digital Output Card

- 0 : None
- 1 : 6 Channels
- 2 : 12 Channels

5 Communication

- 0 : Standard Ethernet interface
- 1 : RS-232/422/485 + Ethernet interface

6 PC Software

- 1 : Free Basic PC Software Observer I
- 2 : Extensive PC Software Observer II
(Link real time)

7 Firmware

- 0 : Basic function
- 1 : With Mathematics, Counter & Totalizer

8 Storage Media

- 1 : 128 MB CF card 6 : 1 G MB CF card
- 2 : 512 MB CF card

9 Case / Mounting

- 1 : Standard Panel Mounting
- 2 : Bench Top / Portable style with handle

10 Special Option

- 0 : None
- 1 : 24 VDC auxiliary power supply
- 2 : 3 Chanel current output
- D : 3 Chanel voltage output
- 5 : Panel mounting with rear power plug
- 6 : Panel mounting with front power switch